

The sanding and finishing process is particularly important to the overall performance and appearance of the timber floor and is an area that offers a wide array of methodologies and coating systems. The practices outlined are those employed broadly throughout the industry, however variations on sandpaper grades and procedures are common. The aim in all cases is to provide a smooth surface with the desired surface coating suitably applied to give an even level of sheen across the body of the floor. It is important that when the floor is being sanded and finished the floor is not walked on by anyone unless under the supervision of the sander and finisher. Simple things such as fly spray, silicone sealer, boots and bare feet can detrimentally affect the floor finish. Generally floors are out of bounds to everyone until the finisher indicates that they can be walked on.

ASSESSING THE FLOOR PRIOR TO SANDING

Prior to sanding the condition of the floor should be assessed to ensure that it is in a condition suitable for sanding. This may include assessing vertical movement at board or end-matched joints, an appraisal of the overall condition of the floor (e.g. degree of cupping in boards, gapping at board edges, signs of moisture) and, if there are signs of abnormal moisture content, it should also include taking and recording moisture contents of the installed floor. This ensures a complete history of the floor, should issues arise in the future. Any issues should be provided in writing to the applicable person (e.g. principal contractor, owner) and an appropriate course of action taken. It is good practice to let the floor "settle" for a period, which may be 3 to 14 days before the sanding process takes place. This period is also beneficial for curing of adhesives where utilised.

PREPARATION FOR SANDING

Punching Nails and filling nail holes

Before the sanding process can begin, ensure that all nails are punched a minimum of 3 mm below the surface of the boards. Any nail that is not suitably punched will potentially damage the sanding equipment and affect the sanding process. It is important to note that secret nailed floors may have been top (face) nailed adjacent to a wall or other areas where access is limited.

The punched nail holes can then be filled with either oil or non-oil based filler. Oil based fillers may bleed oil into the timber and affect the colour of the wood surrounding the nail hole or may not be compatible with various coating products. The colour of the filler should be carefully selected in order to minimise any visual impact of the filler. Many of these products are sold in colours pre-matched to specific species. In mixed species floors or where significant colour variations are present, it is usual to mix or select a neutral colour that is slightly darker than mid range between the extremes of colour. Generally all fillers are slightly darker and this allows for the boards to deepen in colour following finishing and UV exposure.

Filling can be done at this stage or after the first coat of finish is applied. By filling after the first coat any potential for the filler to impact on the surrounding timber through bleed or moisture is minimized. In all cases the filler must completely fill the hole so as not to impact on the finish quality.

Cleaning

The floor requires thorough cleaning to make it free from dirt, grit and debris. These particles, if not removed, can cause deep, uneven scratching in the timber surface requiring substantial additional sanding to remove. The floor should initially be swept followed by vacuuming, paying particular attention to areas which are not effectively cleaned by sweeping, such as gaps underneath the skirting, corners, window sills and the like. The vacuum should have sufficient capacity in terms of both suction and filtration to satisfactorily clean the floor.

It is important to remove any materials that may potentially impact on either the sanding or coating process. Additional care should be taken with silicone based sealants that may have been dropped onto the floor. These products can potentially be widely spread through the sanding process impacting on the bond between the coating and the timber.

Protection

During the sanding and finishing process it is imperative that access to the area of the work be restricted. Any trades working in or around the area can potentially generate dust, wet the floor, introduce silicone based mastics and sealants, walk over the area or generally contaminate it. Clear instructions should also be given to the owner or occupants regarding access, opening windows which may blow dust over the area and time required for coating systems to adequately cure.

SANDING

The sanding operation will vary based on the condition of the floor and the hardness of the flooring species. Where the floor is being sanded for the first time, the sanding process is made up of a number of separate sanding stages, which generally start with a coarse paper and progress to a relatively fine grade of paper. It should be noted that the sanding process is effectively scratching off the surface of the boards, and the reduction in grades of paper means that you start with a severe scratching action and finish with a more subtle scratching action.

Level / Basic Sanding

The level/basic sand, as the name suggests, is to cut the boards level, taking out any ridges or high points in the floor. It typically comprises of three passes with the sanding machine. The level or basic sanding is to provide a level, completely sanded floor - each of the sanding procedures that follow this step are designed to remove the sanding scratches generated by this initial step.

Pass one is done from a small angle or up to a 45 degree angle to the direction of the grain (diagonally). This angle is dependent upon the layout and size of the area to be sanded. A coarser grade of paper is used depending upon the species and the condition of the boards. A lower grade of paper may be used to enhance the effectiveness of the sanding process in a floor that is very uneven or with hard species such as Turpentine or Ironbark.

Each room is sanded starting at a point, which will allow the longest path of travel at approximately 45 degrees (or as is deemed appropriate given the room parameters) to the grain direction (run of boards). The machine is started ensuring that the drum is not touching the boards and walking slowly forward, the drum is eased onto the boards. A slow walking pace and consistent pressure is maintained. At the end of the pass the drum is raised smoothly off the floor and then by walking backwards, pulling the machine, it is eased back onto the floor for the return pass. The power lead, controlled by the operator, must be kept well clear of the drum.

When the original starting point is reached the drum is again gradually raised off the floor. The machine is then moved to the right or left hand side of the first path ensuring an overlap to the first cut path. Sanding continues in that direction, sanding strips and maintaining a similar overlap in each forward and backward pass. When the limit of accessibility has been reached in the corner of the room, the machine is brought back to the starting point and the remainder of the floor is sanded in the same direction and manner but to the opposing side of the first cut. That is, if sanded to the left of the first cut, sanding then takes place to the right of that first cut, ensuring that there is an overlap of around 200mm between the two sides of the floor.

The second pass is carried out on the opposite diagonal to Pass one using a similar grade paper.

The third pass continues in the direction of the boards using a similar grade paper to remove the sanding lines from the action of pass one & two. Typically the operator should start at a point that is a few meters off the side wall. The process of walking speed and easing the drum onto the floor is as previously described.

Once a forward and reverse path is sanded, the machine is moved ensuring an overlap to the previous cut and sanding recommences in the same manner. This process is carried out across the room. When the full width of the room is sanded, the operator should turn 180 degrees and sand the unsanded band of floor.

At the completion of the level or basic sanding the boards should be generally smooth and free from cupping and mismatching of surface

levels between adjacent boards. If this has not been achieved the floor will require additional passes to achieve this state.

The sanding drum should never contact the floor unless moving forward or backward. Doing so will cut a groove into the floor (drum mark), which may not be recoverable. Specialist equipment and manufacturers recommendations, and user instructions should be followed.

Edging

The sanding machine will not be able to sand the boards along the edges of the room, in corners or areas of reduced access such as wardrobes etc. In these areas the boards need to be sanded level and generally blended into the body of the floor. For these areas an edge sander is used. The machine used may vary from either a disc, orbital or belt sander. In all cases, care is necessary to ensure the operation does not dig grooves into the boards and the finished edge is level with the body of the boards.

The most commonly used machine for the edging process is the disc sander. When using this machine the operator should move the machine in a smooth even pattern at board ends and across the grain. The pattern of sanding should overlap and blend into the body of the sanded floor. It is important that the machine is held level as the boards are easily grooved with any uneven pressure. On each movement, the machine should sand an approximately 50 mm section of unsanded floor. Along walls parallel with the boards, the edge sanding machine should be smoothly moved, back and forth, in the direction of the grain overlapping some 100 mm into the body of the sanded floor.

On new and old floors, in good clean condition, finer grit papers are usually sufficient for the purpose of edging.

It may be necessary in areas of very limited access or at the corners of the room, to hand scrape the floor. The scraping action should always be in the direction of the grain with the surface being hand sanded or machine sanded with a smaller machine i.e. orbital sander. With orbital sanders too much pressure or use of an overly aggressive grade of paper can result in deep swirl marks, which will show up in the finish. Once again, care needs to be taken to blend in these hand scraped areas with the body of the floor.

This process is repeated following the second sanding process of the body of the floor.

Finish Sanding

The finish sanding operation involves two separate stages of operation.

Stage 1 - Initial Cuts

The initial cuts utilise a finer grade of paper to that used in the level or basic sanding operation. Typically an F60 - 100 grade paper is used and the floor is sanded in the direction of the grain (board run). The purpose of the initial cuts is to smooth off the coarse sanding marks left by the level or basic sanding. Once a suitable level of smoothness is achieved, the final stage of sanding may be carried out.

Stage 2 - Final Sand

The final sand utilises an even finer grade of paper - once again reducing the depth of scratching and preparing the floor for the coating system. The floor must once again be fully cleaned of dust, grit and debris. Any matter left on the floor will invariably impact upon the quality of the finish.

Typically, the final sand is carried out using a rotary sander, plate orbital sander or similar machine with a 100 - 150 grade paper or screenback. The sanding should be carried out in the direction

of the grain ensuring a smooth action, and applying a balanced control of the machine. If a water based coating system is specified the final sand may need to be carried out using a new or worn 150 mesh screenback dependant on the waterborne system being used (see manufacturers recommendations). The floor is then vacuumed thoroughly and, if required, tack rag cleaned. Special attention should be paid to any potential dust traps in the floor (dig out any dirt or dust and vacuum away). These can contaminate the floor coating system if not cleaned adequately, as the applicator will most certainly pull the dirt onto the body of the floor. It should also be noted that heavy sanding equipment may have the potential to create wheel marks on low density floor boards. Additional care should be taken in these applications.

COATING SYSTEM APPLICATION

The following information is a typical application methodology, which might be utilised for the various finish types with minor product specific variations.

Cleaning

The floor finish will be easily contaminated with any dirt, dust or other extraneous matter left on the floor. It is essential that the area be thoroughly cleaned/vacuumed, paying particular attention to any areas which may have caught dust during the sanding process such as window sills, picture rails, skirtings, power and light switches, light fittings, handrails, etc. The floor needs to be well lit with adequate ventilation. It is important not to have draughts blowing across the floor during the process as they may well introduce contaminants from outside of the actual working area.

Mixing the Coating

The coating material should be well and thoroughly mixed so that all the solids are blended through the body of the liquid. Care should be taken not to stir too quickly or roughly as this may introduce air bubbles to the material impacting on the coating quality. If there are any additives to be used, ensure they are mixed thoroughly into the coating liquid. In all cases follow the manufacturer's instructions.

Cutting In

Using a clean, good quality brush, cut in the finish around the perimeter walls and any other obstructions or areas which may not be accessible to the main applicator. The cutting in should extend out approximately 150 mm into the body of the floor so that the applicator is not required to venture too close to the skirtings and other limited access areas. If any bristles fall out of the brush into the finish, remove immediately.

Applying Coating

The initial coat applied to the raw sanded timber may be either a recognised sealer coat as prescribed by the coating manufacturer or the same material to be used as a finish, except when outside the manufacturer's recommendations. Sealers are available in both water based and solvent based products. The use of a sealer can enhance the development of colour in the timber floor and can reduce the risk of "edge bonding". Penetrating and low rupture sealers are available. In all cases it is imperative to closely follow manufacturer's instructions.

There are many approaches and methods used in the application of floor finishes and coating systems. The following approach is one such application method, which has generally been accepted by the industry.

The applicator as specified by the coating system manufacturer (often a 6 mm Mohair roller or equivalent) is immersed in the coating

contained in a large painter's tray or applicator bucket. These allow the applicator to be lightly squeezed on the shallow portion of the tray to avoid drips. Applying the product to the boards should be carried out in a smooth action starting at one end of the boards and working the product in line with the grain of the timber boards. The finish should be feathered off at the outer edge to minimise any build up of coating at that point. This process should leave a "wet edge" so that each successive section of application blends into the previous section without any ridging, which can occur if the material skins or dries off before the next application strip. The application process should continue in the same manner working from one end of the area to completion. An even, wet look should result without any dry patches.

Filling/Stopping

It is recommended when coating parquetry floors, that filler be trowel applied following the first coat. This aids in reducing the phenomena known as "quilting" where the finish does not flow across joints at board or parquetry edges. Filling of parquet floors may be carried out prior to or following the application of the initial sealer or first coat and is at the discretion of the floor sander. It is not a recommended practice to fill tongue and groove timber floors.

Any nail holes not previously filled and any cracks or other open faults should now be filled with a suitable filling compound that is compatible with the finish type, (Note: ensure the coating system is dry). Generally, a non-oil based filler is best which is suitably colour matched to the timber.

The filler should be installed with a clean bladed applicator. Ensure the filler slightly overfills the hole and has been fully pushed into the void. If the material is not completely filling the void, it may potentially come loose in service. Clean off any filler that is spread over the floor surrounding the hole. Any excess will be sanded away in the light sanding between coats.

Sanding Between Coats

The floor will typically have a slightly rough feel to it after the first coat of finish depending on the system used and the degree of grain raise of the timber created. It is normal for more open grain timbers to exhibit a higher degree of initial grain raise than denser close grain species. The floor requires a light sand after the first coat to remove this roughness and to also key the surface for the next coat of finish. A 150 or finer grit paper or screenback is used at this stage with a rotary sander or similar. It is imperative that the sanding does not expose the timber as this will create further raised grain. The sanding process is required to smooth off the roughness in the coating, not the timber. Edges must be hand or orbital sanded to a similar smoothness.

Cleaning between coats

All dust should again be thoroughly removed from the floor along with any potential dust traps as previously described. Ensure that there are no draughts blowing through the area that could contaminate the final coat(s). In addition it may be prudent to use a tack rag over the floor to remove any dust missed by the vacuum. This will ensure that the floor is as clean as possible for the final coat(s).

Second Coat

The floor should again be edged with a clean brush coming out some 150 mm or more into the body of the floor. The application process is as per the first coat with the applicator being worked along the full lengths of the boards and lightly feathered at the outer edge of each strip of application.

Additional Coats

Any additional coats shall follow the same process of light sand of the previous coat, thorough cleaning and application of the coating. Typically a three coat system is utilised, however all manufacturers' recommendations should be followed in regards to number of coats and sand paper grades, in addition to any requirements of the specifier. Various water and oil based coating systems require a finer grit of paper between coats as compared to the solvent based products.

SAFE WORKING

Working with timber produces dust particles. Protection of the eyes, nose and mouth when sanding, sawing and planing is highly recommended. Refer to tool manufacturers for safe working recommendations for particular items of equipment.

DISPOSAL OF OFFCUTS AND WASTE

For any treated timber, do not burn offcuts or sawdust. Preservative treated offcuts and sawdust should be disposed of by approved local authority methods.

ACKNOWLEDGEMENT

Timber Queensland gratefully acknowledge the contribution of the Australian Timber Flooring Association (ATFA) in the preparation of this Data Sheet.



**TIMBER
QUEENSLAND**
We build Queensland

Timber Queensland Limited

ACN 092 686 756 | ABN 50 092 686 756

500 Brunswick Street, Fortitude Valley
Brisbane Queensland 4006

Phone (07) 3254 1989

Fax (07) 3358 7999

PO Box 2014, Fortitude Valley BC Qld 4006

admin@timberqueensland.com.au

www.timberqueensland.com.au

Whilst every effort is made to ensure the accuracy of advice given, Timber Queensland Limited cannot accept liability for loss or damage arising from the use of the information supplied.